


**Aalborg Universitet
Laboratorie for akustik**

**Driftshåndbog for
Lyddødt rum, lyttekabiner og lytterum**



Hvidovre, den 11.09.02

1. Indholdsfortegnelse	Side
1. Indholdsfortegnelse	2
2. Indledning – Definition af entreprisen	3
3. Telefon- og adresseliste	4
4. Summarisk beskrivelse	5
5. Beskrivelse af anvendte materialer	6
• IAC paneler	6
• IAC døre	7
• IAC vinduer	8
• Vægbeklædning af stof	9
• Akustiklofter	10
• Lysarmaturer	11
• IAC kiler	12
• Hejse system i lyddøde rum	13
6. Tegninger	14

2. Indledning

Definition af entreprisen

Nærværende drifts- og vedligeholdelsesvejledning omfatter entreprisen E11 i forbindelse med nyt akustiklaboratorium på Aalborg Universitet.

Entreprisen omfatter levering og montering af lyddødt rum, lytterum og 2 stk. lyttekabiner.

3. Telefon og adresseliste

Entreprenør :

IAC Nordic A/S (HM akustik)
Jernholmen 14
2650 Hvidovre

Tlf.: + 45 36 77 88 00
Fax: + 45 36 77 50 88

Levering af alle konstruktioner :

IAC Ltd.
IAC House, Morside Road
Winchester
Hampshire, SO23 7US
England

Tlf.: + 44 (0) 1962 873000
Fax: + 44 (0) 1962 873111

Elektriske installationer :

Aalborg Lysteknik
Svendsgade 6
9000 aalborg

Tlf.: +45 98 12 55 54
Fax: +45 98 35 13 77

Parketgulve og tæpper :

Aalborg Gulvservice ApS
Gørtlervej 15
9000 aalborg

Tlf.: +45 98 11 75 22
Fax: +45 98 11 56 22

4. Summarisk beskrivelse

Entreprisen omfatter levering og montering af 4 lokaler som skal anvendes som akustiske laboratorier. Lokalerne opfylder beskrevne akustiske krav i henhold til diverse standarder.

De 4 lokaler er :

- Lytterum – i alt 60 m² – lokale 1.01
- Lyddøde rum – lokale 1.04
- 2 lyttekabiner – hver 9 m² – lokale 1.07 og 1.08

Entreprisen omfatter opbygning af fritstående uafhængige rum inden i råhusets rum. Rummene består af gulve på svingningsdæmpere samt vægge og tage.

Overflader i det lyddøde rum består af skumgummikiler. Der er indbygget wiregulv med fangnet under.

Overflader i lytterum består af parketgulve, tæpper, akustiklofter samt stofbeklædning på vægge.

Indvendige døre og vinduer er indeholdt i entreprisen.

Lysinstallationer incl. 230 volt installation er indeholdt i entreprisen.

Forbindelser, incl. lyddæmpere, til bygningens ventilationsanlæg er indeholdt i entreprisen.

5. Beskrivelse af anvendte materialer

IAC Paneler

Gulv-, væg- og loftpaneler er fabrikat IAC type Moduline udført i gævaniseret stål og Rockwool.

Panelerne kræver ingen vedligeholdelse.

Leverandør :

IAC Nordic A/S
Jernholmen 44
2650 Hvidovre

Tlf.: 36 77 88 00
Fax: 36 77 50 88

IAC døre

Indvendige døre er IAC Acoustic doors udført i pulverlakeret stål .

Vedligeholdelse :

- (1) Hængsler kræver periodisk smøring and kontrol for slitage
- (2) Magnetisk tætningsliste kræver udelukkende renholdelse, evt. med sæbevand. Ved beskadigelse udskiftes magnetisk tætningsliste.
- (3) Tætningsliste kan demonteres enkelt ved at trække den ud af fastholdelsesprofilen.
- (4) Installation af ny tætningsliste. Fastgør først i toppen ved at trykke tætningslisten ind i fastholdelsesprofilen og tryk den nye liste fast med et skruetrækkerblad eller lignende.

Leverandør :

IAC Nordic A/S
Jernholmen 44
2650 Hvidovre

Tlf.: 36 77 88 00

Fax: 36 77 50 88

IAC Vinduer

Indvendige vinduer er IAC Acoustic windows udført i pulverlakeret stål .

Vedligeholdelse :

- (5) Hængsler kræver periodisk smøring and kontrol for slitage
- (6) Magnetisk tætningsliste kræver udelukkende renholdelse, evt. med sæbevand. Ved beskadigelse udskiftes magnetisk tætningsliste.
- (7) Tætningsliste kan demonteres enkelt ved at trække den ud af fastholdelsesprofilen.
- (8) Installation af ny tætningsliste. Fastgør først i toppen ved at trykke tætningslisten ind i fastholdelsesprofilen og tryk den nye liste fast med et skruetrækkerblad eller lignende.

Leverandør :

IAC Nordic A/S
Jernholmen 44
2650 Hvidovre

Tlf.: 36 77 88 00
Fax: 36 77 50 88

Vægbeklædning af stof

Vægge i lytterum og lyttekabiner er beklædt med stof.

Regelmæssig rengøring

Let støvsugning af stofoverflader et par gange om måneden anbefales og vil forlænge stoffets levetid væsentligt. Ved anvendelse af rengøringsmidler bør der kun anvendes anderkendte mærkevare til polstrede varer. Leverandørens anvisninger skal følges.

Brug aldrig rengøringsmidler som er beregnet til hårde overflader. Før et rengøringsmiddel tages i brug, bør der udføres en prøve på et stykke løst stof eller lign.

Pletter bør fjernes hurtigst muligt, helst inden de er tørret ind.

Leverandør :

IAC Nordic A/S
Jernholmen 44
2650 Hvidovre

Tlf.: 36 77 88 00
Fax: 36 77 50 88

Eller direkte fra :

Interface Fabrics
Hopton Mills
Mirford
West Yorkshire WF14 8HE
England

Tlf.: + 44 1924 490591
Fax: + 44 1924 495605

Akustiklofter

I lyttekabiner og lytterum, er der anvendt følgende akustiklofter :

Parafon Fjord Classic i dimension 600x600x18 mm monteret i Movinord T24 synligt skinnesystem.

Rengøring : Børstning eller støvsugning med blød børste. Tåler aftørring med fugtig klud eller svamp.

Dansk importør af Parafon og Movinord :

IAC Nordic A/S
Jernholmen 44
2650 Hvidovre

Tlf.: 36 77 88 00
Fax: 36 77 50 88

Produktion :

Parafon Akustik AB
S – 541 86 Skövde
Sverige

Tlf.: 0046 500 42 42 00
Fax: 0046 500 42 42 42

Lysarmaturer

Loftlys i lyddøde rum er almindelige porcelænsfatninger med 75 W glødepærer.

Gulvlys i lyddøde rum er Halogenspots GU 10 M/KIP med 35 W halogenpærer GU.

Loftbelysning i lytterum og lyttekabiner er Fagerhult Endigo Armaturer HF m/dæmp.
40 W 2G11 lysrør.

Vedligeholdelse : Udskiftning af pærer og lysstofrør efter behov.

Leverandør :

Fagerhult A/S
Baltershøj 13 – 15
2635 Ishøj

Tlf.: 43 55 37 00

Fax: 43 55 37 30

IAC Kiler

Gulv, vægge og loft i det lyddøde rum er beklædt med lydabsorberende kiler af DX30 skumgummi.

Kilerne kræver ingen vedligeholdelse udover eventuel støvsugning med blød børste.

Leverandør :

IAC Nordic A/S
Jernholmen 44
2650 Hvidovre

Tlf.: 36 77 88 00
Fax: 36 77 50 88

Hejsesystem i lyddøde rum

Hejsesystem betjenes fra betjeningskontakter på væggen indenfor den yderste dør.

Systemet må maksimalt belastes med 25 kg. per wire.

Vedligeholdelse : Bevægelige dele smøres efter behov, dog min. en gang om året.

Sikkerhedscertificat vedlægges.

Funktionsbeskrivelse for frekvensomformer (vector 8200) for styring af actuator vedlægges.

Leverandør :

IAC Nordic A/S
Jernholmen 44
2650 Hvidovre

Tlf.: 36 77 88 00
Fax: 36 77 50 88

Eller direkte fra :

Precision Actuation Systems Ltd.
First Road
Blantyre Industrial Estate
Blantyre
Glasgow G72 0BW
Glasgow
Great Britain

Tlf.: 0044 1698 829811
Fax: 0044 1698 829775



PRECISION

ACTUATION SYSTEMS

Precision Actuation Systems Limited

Registered Office:
First Road
Blantyre Industrial Estate
Blantyre
Glasgow G72 0BW
Telephone: (01698) 829811
Facsimile: (01698) 829775
e-mail: sales@precisionactuation.co.uk

Unique Consignment Identifier: WAR0558 #1

Destination: HVIDovre, DENMARK DK-2650

CONSIGNMENT SECURITY CERTIFICATE

I, the undersigned, on behalf of the named below company, certify that to the best of my knowledge:

The consignment to which this document refers has been prepared in accordance with the requirements of the UK National Aviation Security Programme governing known customer procedures and can be considered as 'known cargo'.

I understand that a false declaration may lead to legal action being taken.

Signed: W. Dalziel Name (Block Capitals): W. DAZIEL

Position: DESPATCHER Company: Precision Actuation Systems Ltd.

Date: 21/11/01



Certificate No. FM 26005
BS EN ISO 9001 : 1994



Registration No. SC 141819
VAT Registration No. GB 624 1202 91

These instructions

- inform about the most important technical data, installation, handling and commissioning of the function module.
- are only valid
 - for function modules with the nameplate data E82ZAFS
 - for function modules with the nameplate data E82ZAFS001 (coated)
 - together with the Operating Instructions for the corresponding controller.

Description

The function module E82ZAFS enables the control of Lenze controllers using analog and digital control signals.

Range of application

The function module can be used together with controllers as of the nameplate labelling

- 8200 frequency inverters
 - E82x\xxxxxBxxxXX0x0x (8200 vector/8200 motec/Drive PLC)

Accessories

The delivery package includes a screw driver for the terminals of the function module.




The electrical connection and interfaces remain live for at least 3 minutes after mains separation.

Mechanical installation for 8200 vector




The pins of the FIF interface carry dangerous voltage!

- This function module must only be mounted when the controller is not connected to the mains.
- After the disconnection, wait for 3 minutes before you start working on the module.



1. Disconnect the controller from the mains and wait for at least 3 minutes!
2. Remove and keep blank cover (A).
3. Remove and keep FIF cover (B).
4. Plug the function module (C) onto the FIF interface.

8200vec007




PES:
HF screen termination
by PE connection

8200mat140

5. Assign the terminals of the function module.

Mechanical installation for 8200 motec


E82MV251 / 371



1. Disconnect the controller from the mains and wait for at least 3 minutes before opening the motec !
2. Remove (A) protection cover.
3. Remove and keep (B) FIF cover.
4. Insert function module (C) into the housing [1a].


8200mot136

E82MV551 ... 222



5. Assign the terminals of the function module.

8200mot137



8200mot140

Switch position


Signal to X3/8	Switch position					C0034
	1	2	3	4	5	
0 ... 5 V	OFF	OFF	ON	OFF	OFF	0
0 ... 10 V (default setting)	OFF	OFF	ON	OFF	ON	0
0 ... 20 mA	OFF	OFF	ON	ON	OFF	0
4 ... 20 mA	OFF	OFF	ON	ON	OFF	1
4 ... 20 mA open circuit monitoring	OFF	OFF	ON	ON	OFF	3
-10 V ... +10 V	ON	ON	OFF	OFF	OFF	2




Always set DIP switches and C0034 for the same range, otherwise the controller will misinterpret the analog input signal at X3/8. If a setpoint potentiometer is supplied internally via X3/9, the DIP switch must be set to a voltage range 0 ... 5 V. Otherwise it is not possible to use the complete speed range.

Terminal assignment

Supply of digital inputs/outputs via internal voltage source (X3/20)



Supply of digital inputs/outputs via external voltage source



Min. wiring required for operation

Electrical connection	Screw terminals
Possible connections	rigid: 1.5 mm ² (AWG 16)
	flexible:
	1.0 mm ² (AWG 18)
	0.5 mm ² (AWG 20)
Tightening torques	0.5 ... 0.6 Nm (4.4 .. 5.3 lb-in)

Terminal description

X3	Signal type	Function (bold = Lenze setting)	Level	Technical data		
8	Analog input	Act. or setpoint input (Use DIP switch and C0034 to change the range!)	0 ... +5 V 0 ... +10 V -10 V ... +10 V ¹⁾ 0 ... +20 mA +4 ... +20 mA +4 ... +20 mA (open-circuit monitored)	Resolution: 10 bit Linearity error: ±0.5 % Temperature error: 0.3 % (0 ... +60°C) Input resistance • Voltage signal: > 50 kΩ • Current signal: 250 Ω		
62	Analog output	Output frequency	0 ... +10V	Resolution: 10 bit Linearity error: ±0.5 % Temperature error: 0.3 % (0 ... +60°C) Load capacity: max. 2 mA		
28	Digital inputs	Controller inhibit (CINH)	1 = START	Input resistance: 3.3 kΩ 1 = HIGH (+12 ... +30 V) 0 = LOW (0 ... +3 V) (PLC level, HTL)		
E1 2)		Activation of JOG frequencies JOG1 = 20 Hz JOG2 = 30 Hz JOG3 = 40 Hz			E1	E2
E2			JOG1		1	0
E3			JOG2		0	1
E4	Reversal of direction of rotation CW/CCW rotation	DC brake (DCB)	1 = DCB active			
				E4		
			CW	0		
			CCW	1		
A1	Digital output	Ready for operation	0/+20 V at DC internal 0/+24 V at DC external	Load capacity: 10 mA 50 mA		
9	-	Internal, stabilized DC voltage source for setpoint potentiometer	+5.2 V (ref.: X3/7)	Load capacity: max. 10 mA		
20	-	Internal DC voltage supply for control of digital inputs and output	+20 V (ref.: X3/7)	Max. load capacity Σ I = 40 mA		
59	-	DC supply for A1	+20 V (internal, bridge to X3/20) +24 V (external)			
7	-	GND1, reference potential for analog signals	-	isolated to GND2		
39	-	GND2, reference potential for digital signals	-	isolated to GND1		

¹⁾ Offset (C0026) and gain (C0027) must be adjusted separately for every function module. The adjustment data must be entered again
=> when changing the function module
=> after having loaded the Lenze settings


²⁾ or frequency input 0 ... 10 kHz, configuration under C0425

Motec assembly

motec with function module




- Remove and keep the protection cover of the function module **B** and the FIF cover **A** before assembly! Otherwise, the motec can be damaged!
- Complete the motec nameplate with the sticker **C**, which is delivered together with the function module, before commissioning.



motec without function module



The FIF cover **A** must be plugged on. Otherwise, the motec is not ready for operation!



Commissioning



- If your configuration differs from the Lenze settings, please read the instructions given under "Individual settings".
- Please observe
 - that the setpoint range is set correctly by using the DIP switch at the function module.
 - and that C0034 is adapted to the settings of the DIP switch.
 - Example: Setpoint selection (0 ... 5 V) via potentiometer at X3/7, X3/8 and X3/9
 ⇒ C0034 = 0, DIP switch 1 = OFF, 2 = OFF, 3 = ON, 4 = OFF, 5 = OFF
- The controller is only ready for operation if a HIGH signal is applied to X3/28 (controller enable via terminal).
- Please observe, that the controller can be inhibited through various sources. All sources act like a series connection of switches.
- If the drive does not start although the controller has been enabled through X3/28, check whether the controller is inhibited through a different source.

Step	Lenze setting	Individual setting	Drive reaction	
1. Plug in the keypad				
2. Switch on the mains voltage.	The controller is ready for operation after approx. 1 second. The controller inhibit is active.		The green LED is blinking. Keypad: RDY IMP	
3. Control digital inputs.	E4	E3	E2	<ul style="list-style-type: none"> Adapt the digital input under C0007 or C0410 to your application. The digital input should be set such that the controller can start operation after being enabled via terminal.
	CW rotation	LOW	LOW	
	CCW rotation	HIGH		
4. Enter the setpoint.	Apply a voltage of 0 ... +10 V to X3/8.		<ul style="list-style-type: none"> Depending on the DIP switch position: <ul style="list-style-type: none"> Apply voltage or current to X3/8. Check C0034. 	
5. Enable the controller via terminal.	X3/28 = HIGH (+12 ... +30 V)		The green LED is on. IMP off. The drive should be running now.	

These instructions

- include the most important technical data.
- describe the installation, the handling of the keypad and keypad accessories.
- is valid only
 - for Keypad labelled E82ZBC or E82ZBB,
 - for hand-held terminals labelled E82ZBH,
 - for mounting kits (door) labelled E82ZBHT,
 - for connection cables labelled E82ZWLxxx,
 - together with the Operating Instructions of the corresponding controller.

Description

The keypad enables the communication with Lenze controllers via a keypad.

Scope of application

The keypad can be used with controllers as from the nameplate labelling:

- 8200 frequency inverters
 - E82xxxxxxxBxxxXXVx1x

Required accessories

Connection cable (for hand-held terminal and door installation only)

Function

- Parameterization
- Control (e.g. inhibit and enable)
- Display operating data
- Enter setpoints
- Transfer parameter sets to other controllers

General data and operating conditions of the keypad


Insulation voltage to ground/PE	50 V AC
Enclosure	IP55
Ambient temperature	during operation: -10 ... +60 °C Transport: -25 ... +70 °C Storage: -25 ... +60 °C
Climatic conditions	Class 3K3 acc. to EN 50178 (without condensation, medium relative humidity 85 %)
Dimensions (L x W x H)	75 mm x 62 mm x 23 mm

Installation



The 8200 motec maintains its degree of protection even if the connector cable is inserted and the sealing plug is removed.
The keypad can be connected or disconnected and parameterized during operation.
The rear side of the keypad is bolted to the hand-held terminal (remove rubber coating).
Use the kit E82ZBHT (cut-out 45.3 x 45.3 mm) to mount the keypad e.g. to a control cabinet panel.

8200 vector



With hand-held terminal


1. Plug keypad into the hand-held terminal and bolt (for E82ZBC only).
2. Connect hand-held terminal to the AIF interface using the connection cable.

Without hand-held terminal


1. Plug keypad to the AIF interface.

The keypad is ready when the mains voltage is applied.

8200 motec



1. Plug keypad into the hand-held terminal and bolt (for E82ZBC only).
 2. Remove sealing plug at the heatsink of the motec.
 3. Connect hand-held terminal to the AIF interface using the connection cable.
- The keypad is ready when the mains voltage is applied.



A	Function keys	
Run	Enable controller (X3/28 must be applied to HIGH level)	
Stop	Inhibit controller	
0-2	Change function bar 1 ↔ function bar 2	
← →	To the right/left in the active function bar	
▲ ▼	Increase/decrease value. Scroll: Keep key pressed	
ENTER	Save parameters if → flashing. Confirmation by <i>STOP</i> in the display.	
B	Status displays	
RDY	Ready	
IMP	Pulse inhibit (power outputs inhibited)	
limax	Set current limit exceeded (C0022 (motor mode) or C0023 (generator mode))	
Warn	Warning active	
Trip	Fault active	
C	Bargraph display	
	Value set under C0004 in %. (Default setting: unit load capacity C0056). Display range: - 180 % ... + 180 % (each bar = 20 %)	
D	Function bar 1	
Set	Setpoint input via 0-2 (Not possible with active password protection (display = "LOC"))	
Disp	display function: Display memory unit 1 of the user menu (C0517/1) and active parameter set (active after every mains connection)	
Code	Select codes (display G)	
SubCode	Select subcodes (display H)	
Para	Change parameter of a (sub)code (display I)	
H/L	Display values with more than five digits H: High values (Display "HI") L: Low values (Display "LO")	
E	Function bar 2	
PS	Parameter set 1 ... Select parameter set 4 for change (Display e.g. PS 2 (F)). The parameter sets can only be activated using digital signals (configuration using C007 or C0410.)	
Bus	Select controller on the system bus (CAN) (remote parameterization) (The selected controller (1 ... 63) can be parameterized from the momentary drive. ☐ = function active)	
Menu	Select menu. The user menu is active after every mains connection. If necessary, change to <i>ALL</i> . (<i>USER</i> : Code list in the user menu (C0517). <i>ALL</i> : List of all codes. <i>Func</i> : Specific codes only for the function modules INTERBUS, PROFIBUS-DP and LECOM-B.)	

After every mains switching, you have access to the user menu with the ten most important drive parameters to commission a standard application with linear V, characteristic. For the complete code list please refer to the operating instructions of the controller.

The first code of the user menu (C0517/1) is displayed after mains connection or using **Disp**.

C0050	Output frequency			
-480.00 (Hz)	480.00			
C0034	Setpoint input standard I/O (X3/8)			
-0-	0 ... 5 V / 0 ... 10 V / 0 ... 20 mA			
-1-	4 ... 20 mA			
-2-	-10 V ... +10 V			
-3-	4 ... 20 mA with protection against open circuit (TRIP Sd5, if I < 4 mA)			
C0034	Setpoint input application I/O			
C0034/1 (Subcode 1 of C0034) :	X3/1U, X3/1I			
C0034/2 (Subcode 2 of C0034) :	X3/2U, X3/2I			
-0-	0 ... 5 V / 0 ... 10 V			
-1-	-10 V ... +10 V			
-2-	0 ... 20 mA			
-3-	4 ... 20 mA			
-4-	4 ... 20 mA with protection against open circuit (TRIP Sd5 when I < 4 mA)			
C0007	Configuration digital inputs			
	E4	E3	E2	E1
-0-	CW/CCW	DCB	JOG2/3	JOG1/3
-1-	CW/CCW	PAR	JOG2/3	JOG1/3
-2-	CW/CCW	QSP	JOG2/3	JOG1/3
-3-	CW/CCW	PAR	DCB	JOG1/3
-4-	CW/CCW	QSP	PAR	JOG1/3
-5-	CW/CCW	DCB	TRIP-Set	JOG1/3
-6-	CW/CCW	PAR	TRIP-Set	JOG1/3
-7-	CW/CCW	PAR	DCB	TRIP-Set
-8-	CW/CCW	QSP	PAR	TRIP-Set
-9-	CW/CCW	QSP	TRIP Set	JOG1/3
-10-	CW/CCW	TRIP Set	UP	DOWN
-11-	CW/CCW	DCB	UP	DOWN
-12-	CW/CCW	PAR	UP	DOWN
-13-	CW/CCW	QSP	UP	DOWN
-14-	CCW/QSP	CW/QSP	DCB	JOG1/3
-15-	CCW/QSP	CW/QSP	PAR	JOG1/3
-16-	CCW/QSP	CW/QSP	JOG2/3	JOG1/3
-17- ... -51-	enhanced settings (see operating instructions)			

- CW = clockwise rotation, CCW = counter-clockwise rotation, DCB = DC injection braking, PAR = change-over (PAR1 ↔ PAR2) PAR1 = LOW; PAR2 = HIGH (The corresponding terminal must be assigned to the function "PAR" in PAR1 and in PAR2)
- JOG1/3, JOG2/3 = selection of fixed setpoints (JOG1: JOG1/3 = HIGH, JOG2/3 = LOW, JOG2: JOG1/3 = LOW, JOG2/3 = HIGH, JOG3: JOG1/3 = HIGH, JOG2/3 = HIGH)
- QSP = Quick stop, TRIP Set = external fault, UP/DOWN = motor pot functions

User menu

C0010 0.00	minimum output frequency 480.00	Operation with Lenze geared motors, setting range 1 : 6 → C0010: 14.5 Hz → C0011: 87.0 Hz
C0011 7.50 { 50.00 Hz }	maximum output frequency 480.00 <i>Set in 45 Hz</i>	
C0012 0.00 { 5.00 s }	Acceleration time main setpoint 1300.00 <i>Set in 0.50</i>	Reference: Frequency change 0 Hz ... C0011
C0013 0.00 { 5.00 s }	Deceleration time main setpoint 1300.00	Reference: Frequency change C0011 ... 0 Hz
C0015 7.50 { 50.00 Hz }	V/f rated frequency 960.00	Setting is valid for all permitted mains voltages
C0016 0.00 { depending on the controller }	U _{min} boost 40.0	

C0002 see chapter 'Parameter set transfer'

Change entries in the user menu

Action	Key	Result	Note
1.	Change to the menu "ALL"		Change to function bar 2
2.		[Menu]	
3.		ALL	Select menu "ALL" (list of all codes)
4.			Confirm selection, change to function bar 1
5.	Select user menu		[Code]
6.		0517	Code for user menu
7.	Select memory unit		[SubCode] 001
8.		001 ... 010	Select subcode
9.	Change entry		[Para]
10.		XXXXX	Enter code number The system does not check whether the code number exists! "0" must be entered to delete the entry.
11.		STO-E	Confirm entry and restart "loop" at step 7. to change other memory units

Edit parameters


Change and save parameters
The user menu is active after every mains switching.
Change to the menu ALL to call all codes.
If you should make a mistake during parameterization, load the default setting under C0002 and start again.

Action	Key	Result	Note
1.	Plug in keypad	[Disp] XX.XX Hz	The function [Disp] is active. The first code in the user menu is displayed (C0517/1, default setting: C0050 = output frequency).
2.	If necessary, change to the menu "ALL"		Change to function bar 2
3.		[Menu]	
4.		ALL	Select menu "ALL" (list of all codes)
5.			Confirm selection and change to function bar 1
6.	Inhibit controller		Necessary only, if you change C0002, C0148, C0174 and/or C0469
7.	Set parameters		[Code]
8.		XXXX	Select code
9.		[SubCode] 001	For codes without subcodes: automatic jump to [Para]
10.		XXX	Select subcode
11.		[Para]	
12.		XXXXX	Set parameters
13.		STO-E	Confirm entry, if is flashing
			Confirm entry, if is not flashing; is inactive

Change parameter set (PS)
You can use the keypad only to change over the parameter set, to modify parameters. To activate a parameter set (PS) for operation, you must use digital signals (configuration under C0410 or C0007)!
The function [Disp] displays the currently active PS.

Action	Key	Result	Note
1.	Select function		Change to function bar 2
2.		[PS]	
3.	Select PS		1 ... 4
4.			Confirm selection and change to function bar 1
5.	Set parameters		Proceed as described in the table above

Parameter set transfer

	The PS transfer also changes password-protected codes. For notes about password protection please refer to the operating instructions of the controller.	
Code C0002 PS transfer		
-0-	Function performed	
PS of the controller		
-1- ... -4-	Default setting ⇔ PAR1 ... 4	Overwrite selected PS of the controller with the default setting
-10-	Keypad ⇔ PAR1 / 2 / 3 / 4	Overwrite all PS of the controller with the keypad data
-11- ... -14-	Keypad ⇔ PAR1 ... 4	Overwrite individual PS of the controller with the keypad data
-20-	PAR1 / 2 / 3 / 4 ⇔ Keypad	Copy all PS of the controller to the keypad
PS of a function module on FIF(not for standard I/O or system bus (CAN))		
-31- ... -34-	Default setting ⇔ FPAR1 ... 4	Overwrite selected PS of the function with the default setting
-40-	Keypad ⇔ FPAR1 / 2 / 3 / 4	Overwrite all PS of the function module with the keypad data
-41- ... -44-	Keypad ⇔ FPAR1 ... 4	Overwrite individual PS of the function module with the keypad data
-50-	FPAR1 / 2 / 3 / 4 ⇔ Keypad	Copy all PS of the function module to the keypad
PS controller + function module on FIF (not for standard I/O or system bus (CAN))		
Operation with application I/O: Always transfer PS of the controller and application I/O jointly!		
-61- ... -64-	Default setting ⇔ PAR1 ... 4 + FPAR1 ... 4	Overwrite individual PS with the default setting
-70-	Keypad ⇔ PAR1 / 2 / 3 / 4 + FPAR1 / 2 / 3 / 4	Overwrite all PS with the keypad data
-71- ... -74-	Keypad ⇔ PAR1 ... 4 + FPAR1 ... 4	Overwrite individual PS with the keypad data
-80-	PAR1 / 2 / 3 / 4 + FPAR1 / 2 / 3 / 4 ⇔ Keypad	Copy all PS to the keypad
Please carry out the following steps prior to every PS modification:		
Plug in keypad and inhibit controller with STOP or via terminal (X3/28 = LOW)		
Load default setting		
• Set selection code under C0002, confirm with ENTER		
Transfer PS from controller to keypad		
1. Set 20 or 50 or 80 under C0002, confirm with ENTER		
2. If SRUE is no longer illuminated, all PS are transferred to the keypad.		
Transfer PS from keypad to controller		
1. Set selection code under C0002, confirm with ENTER		
2. If LOAD is no longer illuminated, the PS are transferred to the controller		

6. Tegninger

Oversigtstegning nr. AO – 03082-1 vedlægges.