

PRODUCT DATA

Hand-held Building Acoustics Analyzer Types 2250-J, 2270-J and 2270-K with Building Acoustics Software BZ-7228 or Dual-channel Building Acoustics Software BZ-7229 and optional PULSE Reflex™ Building Acoustics Type 8780

Building Acoustics is the assessment of sound insulation in buildings and building elements. It is important for the well-being of people in their homes, workplace or public venues, thus minimum standards are set in the building regulations of each country.

BZ-7228 software is available for Hand-held Analyzers Type 2250 (2250-J) and Type 2270 (2270-J). It provides the flexibility, ease of use and confidence in your results that field measurements require in building acoustics.

BZ-7229 software turns Type 2270 into a dual-channel building acoustics analyzer (2270-K).

Back at the office, PULSE Reflex Building Acoustics Type 8780 offers versatile post-processing and reporting of your measurement results.



Uses and Features

Uses (BZ-7228 and BZ-7229)

- Measurement of:
 - Airborne sound insulation
 - Façade sound insulation
 - Impact sound insulation

Uses (Type 8780)

- Building acoustics calculation
- Report generation
- Data archiving

Features (BZ-7228 and BZ-7229)

- Complete hand-held building acoustics analyzer
- Measures source and receiving room level spectra
 - Built-in pink and white noise generator
 - Equalisation of sound source spectra
 - Parallel or serial measurements
- Measures reverberation time spectra:
 - Impulse and Interrupted Noise methods
 - Built-in pink and white noise generator

- Measurement position management
- Calculates final results on the spot
 - ISO plus 12 national standards
- Measurement quality indicators
- Colour touch screen user interface
- Sound recording, voice commentary and integrated camera (Type 2270 only) to document test environment
- Single-channel measurements (Type 2250 and 2270)
- Dual-channel measurements (Type 2270 only)
- Complete systems available (single- or dual-channel) including airborne and impact sound sources

Features (Type 8780)

- Calculates building acoustics results
- Analysis and report generation in one application (incorporates Microsoft® Office)
- Automatic data integrity checks
- Combine and compare 'before and after' scenarios in one project
- ISO plus 12 national standards

The Hand-held Analyzer

Fig. 1
Hand-held Analyzers
Type 2250 and 2270



Types 2250 and 2270 are robust, hand-held analyzer platforms designed to host a wide range of sound and vibration measurement applications. Their uses range from assessing environmental and workplace noise to industrial quality control and product development.

Easy to use – their light and ergonomic design make them easy to grip, hold and operate single-handedly. Their high-resolution colour touch screens show the analyzer setup, status and data at a glance, and with a tap of the stylus, you can make quick selections. The “traffic light” indicator, positioned centrally on the pushbutton panel, shows you the current measurement status, even from a distance.

Robust – the hand-held analyzers are built for the tough environment of field measurements. They will

work reliably in rain, dust, heat, frost, day or night, or on a tripod.

To document your measurement, you can add spoken or written comments and make signal recordings during any measurement. (Note that signal recordings require the Signal Recording Option BZ-7226.)

Type 2250 is a single-channel analyzer, while Type 2270 is dual-channel and has additional features such as a built-in camera (allowing you to attach photos to your measurements).

Tasks in Building Acoustics

Fig. 2
Typical configuration
for building acoustics
measurements: sound
source, generator,
analyzer and PC for
reporting





Fig.2 shows a typical configuration for the most common task in building acoustics measurements: airborne sound insulation.

090062/2

Fig.3 shows a typical airborne task setup using a loudspeaker (emitting pink noise) and a number of microphone positions to measure the average source room spectrum L1, and the average receiving room spectrum L2. The average background noise spectrum B2 is also measured to verify the true L2 spectrum.

Fig. 3
Sound source and
microphone positions
for measuring airborne
sound insulation

L1 = Source room level
L2 = Receiving room
level
B2 = Background level
T2 = Reverberation
Time



The average reverberation time spectrum, T2, is measured to correct for the amount of absorption in the receiving room. Finally, the single number result (for example: D_{nTW}) is calculated from the L1, L2, B2 and T2 spectra, and the result can then be compared with the minimum requirements stated in the building regulations.

070141


The sound level depends on the position in the rooms, so several microphone positions are used to measure the average of the source room level, L1, the average of the receiving room level L2 and the average of the background noise level B2. The average reverberation time T2 is also measured using several positions.

In Touch with your Measurements

The spectra required (L1, L2, etc.,) may be measured in any order, to suit field conditions and your preferences. Fig. 4, Fig. 5 and Fig. 6 show typical displays when performing both single- and dual-channel building acoustics measurements.

Fig. 4 shows a typical building acoustics display when you are ready to measure the first L2 position, with source position 1.

Fig. 4
Typical single-channel display when you are ready to measure the first L2 position, with source position 1




The instantaneous (live) spectrum is shown and the high-resolution, colour, touch screen shows the setup, status and data at a glance.

Using the stylus (or navigation pushbuttons) you can directly activate the indicated features (except those with dashed lines in Fig. 4 above).

You can check the generator and loudspeaker signal level by tapping the Generator icon to switch the generator on and off.

Fig. 5
Typical single-channel display
Left: Inspection phase
Right: Save phase



Once the spectrum at position 1 has been measured (for the preset time of 10s), you may inspect the spectrum before saving (see Fig. 5, left).

A yellow 'smiley' icon indicates that you may be able to improve the measurement at one frequency band. Tap the smiley icon to read the explanation and take the necessary action.


Press the Save pushbutton to save the measurement (see Fig. 5, right). You are now ready to measure at position 2.

Fig. 6

Left: Typical dual-channel inspection phase – Façade Sound Insulation is measured with traffic noise as a source. This is indicated by the car 'traffic' icon

Centre: Dual-channel save phase – overview

Right: Type 2270 connected to two microphones through the Dual 10-pole Adaptor



Dual-channel measurements (Type 2270 only) are as easy as single-channel measurements.

In Fig. 6 (left), L1 and L2 Position 3 has been measured and saved. You are now ready to measure in the next dual position. The Overview tab view (Fig. 6, centre) shows all the measured and saved positions, with any smiley icons and annotations (paper clip icon). Any position may be excluded from the average calculation by tapping the check mark.

Reverberation Time

Reverberation Time (RT) is an important parameter describing the acoustic quality of a room or space. It is important for sound levels, speech intelligibility and the perception of music. In building acoustics, it is used to correct for the effects of RT on building acoustics and sound power measurements.

Reverberation Time is the decay time for sound in a room after the excitation stops. It is the time for a 60 dB drop in level, but the decay is usually measured over a 20 or 30 dB drop and then extrapolated to the 60 dB range. It is labelled T20 and T30, respectively, for those two evaluation ranges. The Reverberation Time may range from 0.1 seconds (or less) in anechoic chambers, to 10 or more seconds in large public spaces.

Fig. 7

Reverberation time measurement – measured using the interrupted noise method




Reverberation Time varies between positions in a room, so it is usually measured at several positions. The average can be determined for the RT spectra, or the decays for each frequency band can be averaged and the Reverberation Time spectrum then calculated for the averaged decays (ensemble average).

Reverberation Time can be measured using either Impulsive Excitation (Schroeder Method), from a starting pistol or balloon burst, or by using Interrupted Noise.

All it takes to measure Reverberation Time is to press the Start/Pause pushbutton (and burst the balloon in the case of impulsive excitation). Reverberation times from 0.1 to up to 20 seconds are then measured at peak sound levels up to 143 dB. No trial measurements, no overloads, and the 'traffic light' clearly shows the measurement status from a distance.

A Reverberation Time spectrum, showing T20 and T30, is included in Fig. 8 (left). A yellow 'smiley' icon indicates that you may be able to improve the measurement at one (or more) frequency bands – if just one position shows a red smiley, then the 'master' smiley will also be red. Tap the relevant smiley icon to read the explanation. A reverberation decay curve for 1/3-octave band is included in Fig. 8 (centre) and an overview of results at one frequency band is included in Fig. 8 (right).

Fig. 8
 Reverberation time spectrum (left);
 reverberation decay curve (centre); and
 overview of results (right)



Note: A dedicated Reverberation Time Software module (BZ-7227) is also available. Please contact your Brüel & Kjær representative for details.

Calculations

Standards


Even though the measurement functions (L1, L2, B2, T2) are the same for any building acoustics measurement, the detailed measurement setup and calculation procedures depend on your national building regulations. To ensure that your measurements comply, select the relevant standard before you save your first measurement. This will automatically activate the required setup for measurement and calculation. An overview of the available standards is shown in Table 1, and the calculated parameters in Table 2 (see page 8).

Results

In addition to measurement data, you may also need the receiving room volume and the partition area for some calculations. These can of course be entered using the stylus/navigation pushbuttons on the appropriate instrument display page. You may want to reuse some of your earlier measurements (like a T2 spectrum known from a similar receiving room), to save time. This is also possible, by using a re-use facility in the Explorer display.

The calculations use a reference curve for frequency weighting of the sound reduction spectrum, resulting in a single number like $R'w = 52$ dB (the weighted field sound reduction index according to the ISO 140-4). This means you will know on site if your construction under test fulfils the minimum requirements of the local building regulations. Examples of final results are shown in Fig. 9.

Fig. 9
 With the required data
 measured, final results
 are shown, including
 the reference curve.
 For some results the
 volume of the receiving
 room and the area of
 the partition must be
 entered



Other Tasks

Façade Sound Insulation

Façade sound insulation is a variant of airborne sound insulation, with its own standards. The “source room” is the space outside the façade, and the sound source may be road traffic or a loudspeaker representing outdoor noise. When using traffic noise, the indoor and outdoor sound levels must be measured simultaneously, requiring dual-channel measurements (Type 2270 only). The outdoor microphone positions are flush with the façade, or 2 m in front of it. Calculations are similar to those of the airborne sound insulation, but take the pressure increase at the microphone positions into account.

Impact Sound Insulation

Impact sound is typically caused by footsteps, and to measure impact sound insulation a standardised impact sound source (tapping machine) is placed in the source room. The receiving room levels are measured as for airborne sound insulation, with several positions of the tapping machine. Calculations are like those for airborne sound insulation, except the results represent absolute (not relative) levels.

Wireless Systems

Fig. 10

Optional wireless systems are available to control the sound source for airborne and impact sound insulation measurements



In the field, using a wireless system can speed up measurements by reducing the number of cables and make it easier for you to move between microphone positions and rooms.

Review, Analysis and Report Generation using PULSE Reflex Building Acoustics Type 8780


PULSE Reflex Building Acoustics Type 8780 is the software package for post-processing and reporting of building acoustics measurements made with Type 2250/2270. Measured data can be directly imported from Type 2250/2270 into Type 8780 for viewing, further analysis/re-analysis and reporting of data. In addition to being a post-processing tool, Type 8780 allows you to control Type 2250/2270 software upgrades as well as licensing of the Type 2250/2270 applications.

Many of the primary features of Type 8780 were developed in cooperation with Building Acoustics professionals through user groups and customer clinics. This input resulted in an innovative, customer-driven application incorporating the following unique features:

- ‘Fast-track’ report generation using the PULSE Reflex workflow concept and a library of user-defined report templates
- Versatile handling of measurement data in combining and comparing assessments
- Interactive measurement integrity checks ensuring the best quality of calculation possible
- Available in over nine languages, Type 8780 can generate reports complying with national and international legislation
- Edit measurement data in the interactive display to instantly reveal which factors contribute most to your sound insulation results


Once your measurements are imported, Type 8780 will display data numerically and graphically, in one clear and concise environment, see Fig. 11.

Fig. 11
Typical building acoustics project using Type 8780. Data are presented graphically and numerically with detailed data quality indications, using Type 2250/2270's smiley system




The tabular Data Editor (at the bottom of the screen) presents all measured data and calculation results in detail and provides the controls to refine data as well as to select which measurements to include in the final analysis of a partition. The table groups all information visually, making it very easy to examine detail, while at the same time seeing the overall results. In addition to the numerical data, the table also reveals the quality and status of each item using the smiley system well known from Type 2250/2270 (see Fig. 12) and by colour coding item(s). To reveal detailed information about the status or quality, simply move the cursor over the smiley, or marked cell, and a description will be displayed.

Fig. 12
Close-up of the Data Editor table showing an example of a smiley indicator with the associated explanation



Having graphical data and numerical values displayed simultaneously makes evaluation of the data (and interactive work with the data) a very intuitive process. Changes applied in one part of the interface, such as, editing the graphs or items in a table, will immediately be reflected in the other parts, since PULSE Reflex Building Acoustics immediately recalculates the data and updates all displays and tables.

Fig. 13
Example of a report in standard template format, for example, ISO 140. Standard templates are available for selected national and international standards. All templates can be fully customised. New templates can be derived from the delivered ones, or created from scratch



The software comes with default setups for all relevant displays for the measured data and results, so that a report is just a few clicks away. The flexibility of the software also allows you to create any type of display to combine and compare data as needed, for example to compare data from different partitions or measurements of sound insulation of a partition before and after repair. Displays can also be used to refine data quality graphically, for example, by adjusting the slope line in reverberation decays.

Reporting your Data

PULSE Reflex Building Acoustics includes a very flexible reporting module, which embeds the Microsoft® Office suite installed on your system into the PULSE Reflex environment. This means that you can fully customise your reports and you can create a new report using one of the pre-installed or self-made templates using only a few mouse clicks. See a report example in Fig. 13. Reports can remain linked to the data, so that if you need to revise your analysis, a single click will refresh the report to reflect all the changes.

Information on PULSE Reflex

For more information on PULSE Reflex Building Acoustics and PULSE Reflex visit the website: www.bksv.com/Pulsereflex.

Reviewing and Reporting using Qualifier Type 7830

With Qualifier Type 7830, you can view, recalculate, document and report your data. View any measured and calculated data just as you do in Type 2250/2270. Qualifier's user interface provides a Project Tree for easy browsing and copy/paste across data folders. Data selections can be displayed as tables, 3D plots and graphs. Editing options include the adjustment of the graphical alignment of reverberation decays, manual data entries, copying/pasting of data and changing the calculation standard (where compatible). All changes to data are annotated accordingly.

Reporting Your Data

Qualifier also allows you to report your calculations (or recalculations) using templates based on specific standards such as ISO 140. Templates are available for a selection of national and international standards. You can also customise a template to include your company's logo in the report, or create a report from a blank report template.

Building Acoustics Measurement Standards

Table 1 Building acoustics standards

		International	Germany	Austria	Italy	UK	England Wales	Sweden	Switzerland	France	Spain	Netherlands		USA
Measurement		ISO	DIN	ÖNORM	UNI	BS	BREW	SS	Sia	NF-S31	NBE	NEN	NEN'06	ASTM
Typical Parameters		R' $L'n$	R $L'n$	DnT $L'nT$	Dn Ln	DnT $L'nT$	DnT	R' $L'n$	DnT $L'nT$	$DnAT$ $LnAT$	$DnAT$ $LnAT$	llu lco	DnT,A LnT,A	FTL Ln
Airborne	Lab	10140-2	EN 20140-3	S 5101	8270-1	EN 20140-3		EN 20140-3		051	74-040- 84/3			
	Field	140-4	52210-1	S 5100-1	8270-4	2750-4	BREW	EN 20140-4	181	054, -057	74-040- 84/4	5077	5077	E336-90
	Façade	140-5	52210-5	S 5100-3	8270-5	2750-5		EN 20140-5	181	055, -057	74-040- 84/5	5077	5077	E966-90
Impact	Lab	10140-3	52210-1	S 5101	8270-6	2750-6		EN 20140-6		-052	74-040- 84/6			
	Field	140-7	52210-1	S 5100-2	8270-4	2750-7		EN 20140-7	181	056, -057	74-040- 84/7	5077		E1007-90
RT		3382-2	52212									5077	5077	
Rating	Airborne	717-1	52210-4	S5100-1	8270-7	5821-1, -3	BSEN 717-1	SS- ISO717-1	181	-057	NBECA- 88	5077	NPR 5079	E413-73 E1332-90
	Impact	717-2	52210-4	S5100-2	8270-7	5821-2		SS- ISO717-2	181	-057	NBECA- 88	5077		E989

Table2 Calculated parameters

	Measurement Standards							
	ISO, DIN, ÖNORM, UNI, BS, BREW	SS	Sia	NF	NBE	NEN	NEN'06	ASTM
Basic Standards:	ISO 140 ISO 717	ISO 140 ISO 717	ISO 140 ISO 717	NF S31-05x	ISO 140	NEN 5077	NEN 5077-2006	ASTM E336, 1007, E966, E1332
Airborne Calculated parameters:	<i>D Dn DnT R' R</i> <i>Dw Dw+C Dw+Ctr</i> <i>Dnw Dnw+C Dnw+Ctr</i> <i>DnTw R'w or Rw</i> <i>+C +Ctr</i> <i>+C50-3150 +C50-5000</i> <i>+C 100-5000 +Ctr50-3150</i> <i>+Ctr 100-5000 +Ctr50-5000</i>	<i>ISO plus:</i> <i>Dw8</i> <i>DnTw8</i> <i>R'w8</i> <i>Rw8</i>	<i>ISO plus:</i> <i>DnTw+C-Cv</i>	<i>D DnT R</i> <i>DnATrose</i> <i>DnATroute</i> <i>Rrose</i> <i>Rroute</i>	<i>ISO plus:</i> <i>DA</i> <i>DnAT</i> <i>RA</i> <i>R'A</i>	<i>DnT</i> <i>llu</i> <i>llu;k</i>	<i>DnT</i> <i>DnT,A</i> <i>DnT,A,k</i>	<i>NR NNR</i> <i>FTL</i> <i>NIC</i> <i>NNIC</i> <i>FSTC</i>
Façade Calculated parameters:	<i>R'45° R'tr,s</i> <i>Dls,2m Dls,2m,n</i> <i>Dls,2m,nT Dtr,2m</i> <i>Dtr,2m,n Dtr,2m,nT</i> <i>Dls,2m,w Dls,2m,n,w</i> <i>Dls,2m,nT,w Dls,2m,nT,w+C</i> <i>Dls,2m,nT,w+Ctr</i> <i>Dtr,2m,w Dtr,2m,n,w</i> <i>Dtr,2m,nT,w+C</i> <i>Dtr,2m,nT,w+Ctr</i> <i>R'45°w or R'tr,s,w</i> <i>+C +Ctr</i> <i>+C50-3150 +C50-5000</i> <i>+C 100-5000 +Ctr50-3150</i> <i>+Ctr 100-5000 +Ctr50-5000</i>	See ISO	<i>ISO plus:</i> <i>D45°nT</i> <i>Dls,2m,nT,w</i> <i>+C-Cv</i> <i>Dtr,2m,nT,</i> <i>w+C-Cv</i> <i>D45°nT,w+C</i> <i>tr-Cv</i>	<i>DnT45°</i> <i>DnTtr</i> <i>DnATroute45°</i> <i>DnATroute</i>	<i>ISO plus:</i> <i>R'A45°</i> <i>Dls,2m,nAT</i> <i>Dtr,2m,nAT</i> <i>Dtr,2m,A</i> <i>Dls,2m,A</i> <i>Dls,2m,n,w+C</i> <i>Dls,2m,n,w+Ctr</i> <i>R'A45°AavD,2m,</i> <i>AavD,2m,n,AavD,2m,</i> <i>nT,AavR'A45°AefD,2m,</i> <i>AefD,2m,n,AefD,2m,</i> <i>nT,Aef</i>	<i>Gi</i> <i>GA</i> <i>GA;K</i>	<i>Gi</i> <i>GA</i> <i>GA;K</i>	<i>OILR</i> <i>OITL</i> <i>OITC</i>
Impact Calculated parameters:	<i>L'nt L'nT Ln</i> <i>L'nw L'nTw or Lnw</i> <i>+Ci +Ci 50-2500</i>	<i>ISO plus:</i> <i>L'nw8</i> <i>L'nTw8</i> <i>Lnw8</i>	See ISO	<i>LnT Ln</i> <i>LnAT</i> <i>LnA</i>	<i>ISO plus:</i> <i>LnAT</i> <i>LnA</i>	<i>LnT</i> <i>lco</i>		<i>Ln</i> <i>IIC</i>


Complete System

Type 2250-J, Type 2270-J and Type 2270-K are complete hand-held analyzers needing only a sound source to measure building acoustics and provide sound insulation indices on the spot. However, a wide selection of accessories are available to extend the applications, such as:

- Power amplifier and a choice of sound sources
- Tapping machine for impact sound insulation measurements
- Tripods, extension cables and flat cables
- Microphone and cable for dual-channel applications (2270-J)
- Wireless transmission of generator signal and wireless remote control of tapping machine
- Rotating microphone boom
- Calibrators

Some of these options are shown in Fig. 14. Please refer to separate product data sheets for details. Ask your local Brüel & Kjær representative for more information on complete systems.

Fig. 14
Accessories for
building acoustics
measurements





Accredited Calibration Services at Brüel & Kjær

To ensure traceable measurement history from day one, you can order accredited calibration with your new Type 2250/2270.

We recommend that your Type 2250/2270 is calibrated at a Brüel & Kjær ISO 17025 certified laboratory bi-annually or annually. If any errors are detected by the technician during calibration, repair will be performed prior to returning the instrument to you.

Compliance with Standards

 	<p>CE-mark indicates compliance with the EMC Directive and Low Voltage Directive. C-Tick mark indicates compliance with the EMC requirements of Australia and New Zealand.</p>
Safety	EN/IEC 61010-1, ANSI/UL 61010-1 and CSA C22.2 No.1010.1: Safety requirements for electrical equipment for measurement, control and laboratory use.
EMC Emission	EN/IEC 61000-6-3: Generic emission standard for residential, commercial and light industrial environments. CISPR 22: Radio disturbance characteristics of information technology equipment. Class B Limits. FCC Rules, Part 15: Complies with the limits for a Class B digital device. IEC 61672-1, IEC 61260, IEC 60651 and IEC 60804: Instrumentation standards. Complies with Canadian standard ICES-001
EMC Immunity	EN/IEC 61000-6-2: Generic standard – Immunity for industrial environments. EN/IEC 61326: Electrical equipment for measurement, control and laboratory use – EMC requirements. IEC 61672-1, IEC 61260, IEC 60651 and IEC 60804: Instrumentation standards

Specifications – Type 2250/2270 Platform

Microphone

SUPPLIED MICROPHONE

Type 4189: Prepolarized Free-field ½" Microphone
or

Type 4190: Free-field ½" Microphone

Nominal Open-circuit Sensitivity: 50 mV/Pa (corresponding to
-26 dB re 1 V/Pa) ± 1.5 dB

Capacitance: 14 pF (at 250 Hz)

MICROPHONE PREAMPLIFIER ZC-0032

Nominal Preamplifier Attenuation: 0.25 dB

Connector: 10-pin LEMO

Extension Cables: Up to 100 m in length between the microphone
preamplifier and Type 2250/2270, without degradation of the
specifications

Accessory Detection: Windscreen UA-1650 can be automatically detected when fitted over ZC-0032

MICROPHONE POLARIZATION VOLTAGE

Selectable between 0 V and 200 V

SELF-GENERATED NOISE LEVEL

Typical values at 23°C for nominal microphone open-circuit sensitivity:

Weighting	Microphone	Electrical	Total
"A"	14.6 dB	12.4 dB	16.6 dB
"B"	13.4 dB	11.5 dB	15.6 dB
"C"	13.5 dB	12.9 dB	16.2 dB
"Z" 5 Hz–20 kHz	15.3 dB	18.3 dB	20.1 dB
"Z" 3 Hz–20 kHz	15.3 dB	25.5 dB	25.9 dB

Interface

KEYBOARD

Pushbuttons: 11 keys with backlight, optimised for measurement control and screen navigation

ON-OFF BUTTON

Function: Press 1 s to turn on; press 1 s to enter standby; press for more than 5 s to switch off

STATUS INDICATORS

LEDs: Red, amber and green

DISPLAY

Type: Transflective back-lit colour touch screen 240 × 320 dot matrix

Colour Schemes: Five different – optimised for different usage scenarios (day, night, etc.)

Backlight: Adjustable level and on-time

USER INTERFACE

Measurement Control: Using pushbuttons on keyboard

Setup and Display of Results: Using stylus on touch screen or pushbuttons on keyboard

Lock: Keyboard and touch screen can be locked and unlocked

USB INTERFACE

USB 2.0 OTG Micro AB and USB 2.0 Standard A sockets

MODEM INTERFACE

Connection to Internet through GPRS/EDGE/HSPA modem connected through the USB Standard A Socket

Supports DynDNS for automatic update of IP address of host name

PRINTER INTERFACE

PCL printers, Mobile Pro Spectrum thermal printer or Seiko DPU S245/S445 thermal printers can be connected to USB socket

MICROPHONE FOR COMMENTARY

Microphone, which utilises Automatic Gain Control (AGC), is incorporated in underside of analyzer. Used to create voice annotations for attaching to measurements

CAMERA (TYPE 2270 ONLY)

Camera with fixed focus and automatic exposure is incorporated in underside of analyzer.

Used to create image annotations for attaching to measurements

Image Size: 2048 × 1536 pixels

Viewfinder Size: 212 × 160 pixels

Format: jpg with exif information

Inputs/Outputs

SECURE DIGITAL SOCKET

2 × SD sockets

Connect SD and SDHC memory cards

LAN INTERFACE SOCKET

- Connector: RJ45 Auto-MDIX
- Speed: 100 Mbps
- Protocol: TCP/IP

INPUT SOCKET (2 – TYPE 2270 ONLY)

Connector: Triaxial LEMO

Input Impedance: $\geq 1 \text{ M}\Omega$

Direct Input: Max. input voltage: $\pm 14.14 \text{ V}_{\text{peak}}$

CCLD Input: Max. input voltage: $\pm 7.07 \text{ V}_{\text{peak}}$

CCLD Current/voltage: 4 mA/25 V

TRIGGER SOCKET

Connector: Triaxial LEMO

Max. Input Voltage: $\pm 20 \text{ V}_{\text{peak}}$

Input Impedance: $> 47 \text{ k}\Omega$

Precision: $\pm 0.1 \text{ V}$

OUTPUT SOCKET

Connector: Triaxial LEMO

Max. Peak Output Level: $\pm 4.46 \text{ V}$

Output Impedance: 50Ω

HEADPHONE SOCKET

Connector: 3.5 mm Minijack stereo socket

Max. Peak Output Level: $\pm 1.4 \text{ V}$

Output Impedance: 32Ω in each channel

Power

EXTERNAL DC POWER SUPPLY REQUIREMENTS

Used to charge the battery pack in the analyzer

Voltage: 8 – 24 V DC, ripple voltage $< 20 \text{ mV}$

Current Requirement: Min. 1.5 A

Power Consumption: $< 2.5 \text{ W}$, without battery charging, $< 10 \text{ W}$ when charging

Cable Connector: LEMO Type FFA.00, positive at centre pin

EXTERNAL AC MAIN SUPPLY ADAPTOR

Part No.: ZG-0426

Supply Voltage: 100 – 120/200 – 240 VAC; 47 – 63 Hz

Connector: 2-pin IEC 320

BATTERY PACK

Part No.: QB-0061 Rechargeable Li-Ion battery

Voltage: 3.7 V

Capacity: 5200 mAh nominal

Typical Operating Time:

- Single-channel: $> 11 \text{ h}$ (screen backlight dimmed); $> 8.5 \text{ h}$ (full screen backlight)
- Dual-channel: $> 7.5 \text{ h}$ (full screen backlight)

Use of external interfaces (LAN, USB, WLAN) will decrease battery operating time

Battery Cycle Life: > 500 complete charge/discharge cycles

Battery Aging: Approximately 20% loss in capacity per year

Battery Indicator: Remaining battery capacity and expected working time may be read out in % and in time

Battery Fuel Gauge: The battery is equipped with a built-in fuel gauge, which continuously measures and stores the actual battery capacity in the battery unit

Charge Time: In analyzer, typically 10 hours from empty at ambient temperatures below 30°C. To protect the battery, charging will be terminated completely at ambient temperatures above 40°C. At 30 to 40°C charging time will be prolonged. With external charger ZG-0444 (optional accessory), typically 5 hours

Note: It is not recommended to charge the battery at temperatures below 0°C (32°F) or over 50°C (122°F). Doing this will reduce battery lifetime

CLOCK

Back-up battery powered clock. Drift $< 0.45 \text{ s}$ per 24 hour period

Storage

INTERNAL FLASH-RAM (NON-VOLATILE)

For user setups and measurement data

- 512 MB

EXTERNAL SECURE DIGITAL MEMORY CARD

SD and SDHC Card: For store/recall of measurement data

USB MEMORY STICK

For store/recall of measurement data

Environmental

WARM-UP TIME

From Power Off: <2 minutes

From Standby: <10 seconds for prepolarized microphones

TEMPERATURE

IEC 60068-2-1 & IEC 60068-2-2: Environmental Testing. Cold and Dry Heat.

Operating Temperature: -10 to +50°C (14 to 122°F), <0.1 dB

Storage Temperature: -25 to +70°C (-13 to +158°F)

HUMIDITY

IEC 60068-2-78: Damp Heat: 90% RH (non-condensing at 40°C (104°F))

Effect of Humidity: <0.1 dB for 0% <RH <90% (at 40°C (104°F) and 1 kHz)

MECHANICAL

Environmental Protection: IP44

Non-operating:

IEC 60068-2-6: Vibration: 0.3 mm, 20 m/s², 10 – 500 Hz

IEC 60068-2-27: Shock: 1000 m/s²

IEC 60068-2-29: Bump: 4000 bumps at 400 m/s²

WEIGHT AND DIMENSIONS

650 g (23 oz.) including rechargeable battery

300 × 93 × 50 mm (11.8 × 3.7 × 1.9") incl. preamplifier and microphone

User Interface

USERS

Multi-user concept with login. Users can have their own settings with jobs and projects totally independent of other users

PREFERENCES

Date, Time and Number formats can be specified per user

LANGUAGE

User Interface in Catalan, Chinese (People's Republic of China), Chinese (Taiwan), Croatian, Czech, Danish, English, Flemish, French, German, Hungarian, Japanese, Italian, Korean, Polish, Portuguese, Romanian, Russian, Serbian, Slovenian, Spanish, Swedish and Turkish

HELP

Concise context-sensitive help in English, French, German, Italian, Japanese, Korean, Polish, Portuguese, Romanian, Serbian, Slovenian and Spanish

UPDATE OF SOFTWARE

Update to any version (from 4.0 and up) using BZ-5503 through USB or update via Internet:

WEB PAGE

Connect to the analyzer using an Internet browser supporting JavaScript[®]. The connection is password protected:

- Guest level: for viewing only
- Administrator level: for viewing and full control of the analyzer

Specifications – Building Acoustics Software BZ-7228 and Dual-Channel Building Acoustics Software BZ-7229

Specifications apply to BZ-7228 and BZ-7229 unless otherwise stated. Dual-Channel Building Acoustics Software BZ-7229 is for Type 2270 only

STANDARDS

Conforms with the relevant parts of the following:

- IEC 61672-1 (2002-05) Class 1
- IEC 60651 (1979) plus Amendment 1 (1993-02) and Amendment 2 (2000-10), Type 1
- ANSI S1.4-1983 plus ANSI S1.4A-1985 Amendment, Type 1
- IEC 61260 (1995-07) plus Amendment 1 (2001-09), 1/1-octave Bands and 1/3-octave Bands, Class 0
- ANSI S1.11-1986, 1/1-octave Bands and 1/3-octave Bands, Order 3, Type 0-C
- ANSI S1.11-2004, 1/1-octave Bands and 1/3-octave Bands, Class 0
- ISO, SS, DIN, Önorm, BS, BREW, Sia, UNI, NF-S31, NBE, NEN, NEN'06, ASTM, see tables under Building Acoustics Measurement Standards on page 8

Note: The International IEC Standards are adopted as European standards by CENELEC. When this happens, the letters IEC are replaced with EN and the number is retained. Type 2250/2270 also conforms to these EN Standards

CHANNELS (TYPE 2270 ONLY)

All measurements are made from either Ch.1 or Ch.2 or both simultaneously

TRANSDUCERS

Transducers are described in a transducer database with information on Serial Number, Nominal Sensitivity, Polarization Voltage, Free-field Type, CCLD required, Capacitance and additional information.

The analogue hardware is set up automatically in accordance with the selected transducer

CORRECTION FILTERS

For microphone Types 4189, 4190, 4191, 4193, 4950 and 4952, BZ-7228/7229 are able to correct the frequency response to compensate for sound field and accessories

Broadband Analysis

DETECTORS

A- and C-weighted: Broadband detectors with Fast exponential time weighting

Overload Detector: Monitors the overload outputs of all the frequency weighted channels

Under Range Detector: Monitors the under range of all the frequency weighted detectors when set to High Range. Under range is set if level is below lower limit of Linear Operating Range

Type 2270: Detectors available for both Ch. 1 and Ch. 2

MEASUREMENTS

L_{AF} and L_{CF} for Display as Numbers or Quasi-analogue Bars

MEASURING RANGES

When using Microphone Type 4189:

Dynamic Range: From typical noise floor to max. level for a 1 kHz pure tone signal, A-weighted:

Single Range: 16.6 to 140 dB

High Range: 28.5 to 140 dB

Low Range: 16.6 to 110 dB

Primary Indicator Range: In accordance with IEC 60651, A-weighted:

Single Range: 23.5 to 123 dB

High Range: 41.7 to 123 dB

Low Range: 23.5 to 93 dB

Linear Operating Range: In accordance with IEC 61672, A-weighted:

1 kHz:

Single Range: 24.8 to 140 dB

High Range: 43.0 to 140 dB

Low Range: 24.8 to 110 dB

Frequency Analysis

CENTRE FREQUENCIES

1/1-octave Band Centre Frequencies: 63 Hz to 8 kHz

1/3-octave Band Centre Frequencies: 50 Hz to 10 kHz

MEASURING RANGES

When using Microphone Type 4189:

Dynamic Range: From typical noise floor to max. level for a pure tone signal at 1 kHz 1/3-octave:

Single Range: 1.1 to 140 dB

High Range: 11.3 to 140 dB

Low Range: 1.1 to 110 dB

Linear Operating Range: In accordance with IEC 61260:

Single Range: ≤20.5 to 140 dB

High Range: ≤39.1 to 140 dB

Low Range: ≤20.5 to 110 dB

Internal Generator

Built-in pseudo-random noise generator

Spectrum: Selectable Pink or White

Crest Factor:

Pink Noise: 4.4 (13 dB)

White Noise: 3.6 (11 dB)

Bandwidth: Follows measurement frequency range

Lower Limit: 50 Hz (1/3-oct.) or 63 Hz (oct.)

Upper Limit: 10 kHz (1/3-oct.) or 8 kHz (oct.)

Output Level: Independent of bandwidth

Max.: $1 V_{rms}$ (0 dB)

Gain Adjustment: -80 to 0 dB

When bandwidth is changed, the level for all bands is automatically adjusted to comply with the set output level

Correction Filters: For sound sources Type 4292-L, Type 4295 and Type 4296: Flat or Optimum

Turn-on Time and Turn-off Time: Equivalent to RT = 70 ms

Repetition Period: 175 s

Output Connector: Output Socket

Control: See Measurement Control

External Generator

Selectable as alternative to Internal Generator

For controlling external noise generator

Levels: 0 V (Generator off), 3.3 V (Generator on)

Rise-time and Fall-time: 10 μ s

Control: See Measurement Control

Measurements

Measurements are done at a number of positions and categorised in functions (L1 for Source Room levels, L2 for Receiving Room levels, B2 for Receiving Room Background noise levels and T2 for Receiving Room Reverberation Time measurements)

LEVELS L1, L2 AND B2

L_{ZF} spectrum for display only

L_{Zeq} in 1/1-octave or 1/3-octave bands

L1 and L2 simultaneously or as single channels

Averaging time: 1 s to 1 hour

Range (L1 and L2 simultaneously only): Autorange or manually set to High Range or Low Range

Averaging: Up to 10 source positions each with up to 10 measurement positions or up to 100 measurements may be averaged

Status Indications: Overload, under range, etc.

Crosstalk:

5 Hz – 10 kHz < -110 dB

10 kHz – 20 kHz < -100 dB

REVERBERATION TIME T2

T20 and T30 in 1/1-octave or 1/3-octave bands

Decays: L_{Zeq} spectra sampled at 5 ms intervals

Evaluation Range: -5 to -25 dB for T20 and -5 to -35 dB for T30

Measurement Time: Automatic selection of measurement time for the decays based on the actual reverberation time of the room

Maximum Measurement Time: From 2 to 20 s

Averaging: T20 and T30 measurements can be averaged (arithmetic averaging or ensemble averaging)

T20 and T30 Calculation: From slope in evaluation range

Slope Estimation: Least squares approximation

Quality Indicators: Quality indicators with status information like Overload, Curvature in %, etc.; extensive list of Status information
Quality Indicators are available on reverberation time spectra for each frequency band, and as overall quality indicators for each measurement position and for the averaged result

Reverberation Time Range: Max. 20 s, min. 0.1 – 0.7 s, depending on bandwidth and centre frequency

Manual Data Entry: A T2 value may be entered in any frequency band of a measured spectrum

Measurement Displays

OVERVIEW

Table of measurement positions for each function (L1, L2, B2 or T2) with readout for selectable frequency band on each position together with quality indicator.

Positions can be included/excluded from average

SOUND LEVEL SPECTRUM

L_{ZF} spectrum plus A and C broadband bars

L_{Zeq} spectrum for L1@Pos, L2@Pos, B2@Pos, L1, L2, B2, L1-L2, L2-B2

Y-axis: Range: 5, 10, 20, 40, 60, 80, 100, 120, 140 or 160 dB. Auto-zoom or auto scale available

Cursor: Readout of selected band quality indicator for each frequency band

REVERBERATION TIME SPECTRUM

One or two spectra can be displayed

Y-axis: Range: 0.5, 1, 2, 5, 10 or 20 s. Auto zoom available

Cursor: Readout of selected band quality indicator for each frequency band

SPECTRUM TABLE

One or two spectra can be displayed in tabular form

DECAY

Decay curve for a position or the room average available for each frequency band (if Ensemble Average selected)

Display of evaluation range and regression line

Readout of Curvature in %

Y-axis: Range: 5, 10, 20, 40, 60, 80, 100, 120, 140 or 160 dB. Auto zoom or auto scale available

Result Displays

OVERVIEW

Table of measurement positions for all functions (L1, L2, B2 or T2) with readout of quality indicators.

Positions can be included/excluded from result

CALCULATIONS

Shows the sound reduction index (spectrum and weighted) according to the selected standard, along with the reference curve (if any), or deviations (from the reference curve). See Table 2 on page 9

Measurement Control

Measurement Sequence: Supports measuring:

- at all microphone positions before using another source
- at a microphone position for all sources before measuring at a new position
- at subsequent microphone positions without source information
- at manually selected source and microphone positions

Measurements are started manually and can be automatically stored on completion of measurement

Generator (L1, L2 and T2): The noise generator is turned on and off automatically

Escape Time: 0 to 60 s

Build-up Time: 1 to 10 s

The generator can be turned on and off manually for checking equipment and sound levels

EXCITATION T2

Interrupted Noise: Measurements are started manually and can be automatically stored on completion of measurement

Number of Decays per Measurement: 1 to 100, ensemble averaged into one decay

Impulse: Manual start of first measurement. When level (say from starter pistol) exceeds the user-selected trigger level, the decay is recorded and backwards integration performed (Schroeder method). The trigger can then be armed automatically for measuring at the next position

Signal Recording: Recording of the Z-weighted measured signal can be done at each position*

* Signal Recording requires an SD card or USB stick for data storage and a license for Signal Recording Option BZ-7226

Measurement Status

On Screen: Information such as *overload*, *awaiting trigger* and *running/paused* are displayed on screen as icons or text

Traffic Light: Red, yellow and green LEDs show measurement status and instantaneous overload as follows:

- Yellow LED flashing every 5 s = stopped, ready to measure
- Green LED flashing slowly = awaiting trigger or calibration signal
- Green LED on constantly = measuring
- Yellow LED flashing slowly = paused, measurement not stored
- Red LED flashing quickly = intermittent overload, calibration failed

Calibration

Initial calibration is stored for comparison with later calibrations

Acoustic: Using Sound Calibrator Type 4231 or custom calibrator. The calibration process automatically detects the calibration level when Sound Calibrator Type 4231 is used

Electrical: Uses internally generated electrical signal combined with a typed-in value of microphone sensitivity

Calibration History: Up to 20 of the last calibrations made are listed and can be viewed on the instrument

Signal Monitoring

Input signal A-, C- or Z-weighted can be monitored using an earphone/headphones connected to the headphone socket

Headphone Signal: Input signal can be monitored using this socket with headphones/earphones

Gain Adjustment: –60 dB to 60 dB

Voice Annotations

Voice annotations can be attached to the building acoustics project and to measurements at each position

Playback: Playback of voice annotations or signal recordings can be listened to using earphone/headphones connected to the headphone socket

Gain Adjustment: –60 dB to 0 dB

Text & Image Annotations

Text and image (Type 2270 only) annotations can be attached to the building acoustics project and to measurements at each position

Data Management

Project Template: Defines the display and measurement setups

Project: Measurement data for all positions defined in source room (L1) and in receiving room (L2, B2 and T2) are stored with the Project Template

Re-use of data: Data for L1, B2 or T2 in one project can be re-used in another project

Job: Projects are organised in Jobs

Explorer facilities for easy management of data (copy, cut, paste, delete, rename, view data, open project, create job, set default project name)

Specifications – Signal Recording Option BZ-7226

Signal Recording Option BZ-7226 is enabled with a separate license. It works with all the software for Type 2250/2270: Sound Level Meter, Frequency Analysis, Logging Software, Enhanced Logging Software and Reverberation Time Software

For data storage, Signal Recording requires either:

- SD Card
- USB Memory Stick

RECORDED SIGNAL

A-, B-, C- or Z-weighted signal from the measurement transducer

AUTOMATIC GAIN CONTROL

The average level of the signal is kept within a 40 dB range, or the gain can be fixed

PLAYBACK

Playback of signal recordings can be listened to using the earphone/headphones connected to the headphone socket

SAMPLING RATE AND PRE-RECORDING

The signal is buffered for the pre-recording of the signal. This allows the beginning of events to be recorded even if they are only detected later.

Sampling Rate (kHz)	Maximum Pre-recording (s)	Sound Quality	Memory (KB/s)
8	470	Low	16
16	230	Fair	32
24	150	Medium	48
48	70	High	96

RECORDING FORMAT

The recording format is 16-bit wave files (extension .wav) attached to the data in the project, easily played-back afterwards on a PC using BZ-5503, Type 7820 or 7825. Calibration information is stored in the .wav file, allowing PULSE to analyse the recordings

Specifications – PULSE Reflex Building Acoustics Type 8780

PULSE Reflex Building Acoustics is the software package for post-processing and reporting of building acoustics measurements made with Type 2250/2270.

In addition, PULSE Reflex Building Acoustics provides functionality to manage and maintain Type 2250/2270:

TYPE 2250/2270 SOFTWARE UPGRADES AND LICENSES

PULSE Reflex Building Acoustics controls Type 2250/2270 software upgrades and licensing of the Type 2250/2270 applications

ON-LINE DISPLAY OF TYPE 2250/2270 DATA

Measurements on Type 2250/2270 can be controlled from the PC and displayed on-line with the PC, using the same user interface on the PC as on Type 2250/2270

INTERFACE TO TYPE 2250/2270

USB ver. 2.0, LAN Ethernet connection

MINIMUM PC

- Pentium processor 2.0 GHz with 2 GB of RAM
- 100 GB hard disk with 2 GB free space
- Microsoft® Windows XP® Professional (Service Pack 3)

- Microsoft® Office 2003 (Service Pack 2)
- DVD drive

RECOMMENDED PC

- 2.5 GHz Intel® Core™ 2 Duo-processor, or better
- 4 GB of memory; for 64-bit Windows® 7: 8 GB memory
- 160 GB Solid-State Drive (SSD) with 20 GB free space
- DVD-RW drive
- 1 GB Ethernet connection
- 1 COM port, either integrated or through a USB adaptor
- Microsoft® Windows® operating system:
 - Windows® XP Professional (SP 3), 32-bit only
 - Windows Vista® Ultimate (SP 2), 32-bit only
 - Windows Vista® Business (SP 2), 32-bit only
 - Windows® 7 (SP 1), 32- and 64-bit
- Microsoft® Office:
 - Microsoft® Office 2003 (SP 3)
 - Microsoft® Office 2007 (SP 2)
 - Microsoft® Office 2010 (with 32-bit only)
- Microsoft® SQL Server® 2008 Express Edition (SP 1) – included
- Adobe® Reader® 10.1 (US version included on the Installation DVD)

Specifications – Qualifier Type 7830

STANDARDS

See Tables 1 and 2 under Building Acoustics Measurement Standards on page 8

LANGUAGES

English, French and German

VIEWS

Result Level Views: A collection of views showing the resulting single values, reduction curve and underlying average curves (L1, L2, B2 and T20/T30)

Average Level Views: Each of the parameters (L1, L2 and B2) has a corresponding view showing all of the measurement curves included in the average calculation and a view of the resulting average curve. In T20/T30 Average mode, it is possible to see all of the T20/T30s included in the average calculation. In Ensemble Average mode, it is possible to see the averaged 3D and averaged single frequency decay curves. Both modes gives the user the ability to see the resulting T20/T30 spectrum

Position Level Views: Each of the level measurements (L1, L2 and B2) can be viewed as a spectrum. In addition, the T2 reverberation measurement can be viewed as 3D-multispectra and as single frequency decay curves. Furthermore it is possible to see the calculated T20/T30 spectrum

Data Sheets: All of the measurement and the most relevant intermediate and final results can be viewed as values in a table (not decays)

CURSOR READ-OUT:

All curves have cursor read-out

MANUAL INPUT

Allows graphical input and modification of the regression line in reverberation decay curves. Calculated sound reduction curves can also be adjusted graphically (The impact on the single value index is shown simultaneously). To give maximum flexibility, position, average and

calculated data can be overridden by manually inputting data in the data sheets

CALCULATIONS

Supports calculation of insulation and reverberation tasks. Insulation calculations include airborne and impact sound insulation (lab/field). In addition, airborne facade calculation is supported.

REPORT GENERATION

Based on document templates it is possible to make reports conforming to the supported standards

OUTPUT

Relevant views and sheets can be printed or exported to the clipboard. Text or graphs may be transferred to word processors in .rtf (Rich Text Format)

HELP

On-line context-sensitive and user-guide

DATA TRANSFER

- Via RS–232 serial interface: Speeds from 1200 bps to 115200 bps
- Via PC card

MINIMUM PC

- Pentium® III (or newer)
- 256 MB RAM
- SVGA graphics display/adaptor
- Sound card
- CD-ROM drive
- Mouse
- USB
- Serial RS–232 port (to download data directly from the analyzer*)
- PC card slot (for data transfer)
- Windows® XP, Windows Vista® or Windows® 7

* Alternatively, use USB to RS–232 Converter UL-0250

Ordering Information

Type 2250-J Hand-held Analyzer Type 2250 with Sound Level Meter Software BZ-7222 and Building Acoustics Software BZ-7228

Type 2270-J Hand-held Analyzer Type 2270 with Sound Level Meter Software BZ-7222 and Building Acoustics Software BZ-7228

Type 2270-K Hand-held Analyzer Type 2270 with Sound Level Meter Software BZ-7222 and Dual-channel Building Acoustics Software BZ-7229

Included with Hand-held Analyzer Types 2250-J, 2270-J and 2270-K:

- Sound Level Meter Application BZ-7222
- Building Acoustics Software BZ-7228 or BZ-7229 (for Type 2270-K)
- Prepolarized Free-field 1/2" Microphone Type 4189
- Microphone Preamplifier ZC-0032
- USB Standard A to USB Micro B Interface Cable AO-1494, 1.8 m (6 ft)

Systems and Kits

Type 2250-J-001 Building Acoustics System including Hand-held Analyzer Type 2250-J, OmniPower Sound Source Type 4292-L and Power Amplifier Type 2734-A

Type 2270-J-001 Building Acoustics System including Hand-held Analyzer Type 2270-J, OmniPower Sound Source Type 4292-L and Power Amplifier Type 2734-A

Included with Building Acoustics System Types 2250-J-001 and 2270-J-001:

- Hand-held Analyzer Type 2250-J or 2270-J
- OmniPower Sound Source Type 4292-L (tripod included)
- Power Amplifier Type 2734-A

- Environmental Software DVD BZ-5298 (including Measurement Partner Suite BZ-5503)
- 90 mm dia. Windscreen UA-1650 with AutoDetect
- Tripod Extension for Hand-held Analyzer UA-1651
- Adaptor for Standard Tripod Mount UA-1673
- Wrist Strap DH-0696
- Travel Bag KE-0440
- Protective Cover KE-0441
- Hinged Cover FB-0699 (for Type 2270) or Hinged Cover FB-0679 (for Type 2250)
- Earphones HT-0015
- Five Extra Styli UA-1654
- LAN Interface Cable AO-1449
- Battery Pack QB-0061
- Mains Power Supply ZG-0426

- Sound Calibrator Type 4231, Class 1 and LS, 94 and 114 dB, 1 kHz
- Flight Case KE-0449 for OmniPower Sound Source Type 4292-L
- Carrying Bag KE-0364 for Type 4292-L Tripod
- Lightweight Tripod UA-0801
- Windscreen for 1/2" Microphones UA-0237, 90 mm diameter
- Signal Cable AO-0523-D-100, Triaxial LEMO to XLR3M, 10 m (33 ft)
- Speaker Cable AQ-0673, Speakon® 4-pin (M) to Speakon 4-pin (M), 10 m (33 ft)
- PULSE Reflex Building Acoustics Type 8780

Type 2270-K-001 Dual-channel Building Acoustics System including Type 2270-K, OmniPower Sound Source Type 4292-L and Power Amplifier Type 2734-A

Included with Building Acoustics System Type 2270-K-001:

- Hand-held Analyzer Type 2270-K
- OmniPower Sound Source Type 4292-L (tripod included)
- Power Amplifier Type 2734-A
- Sound Calibrator Type 4231, Class 1 and LS, 94 and 114 dB, 1 kHz
- Flight Case KE-0449 for OmniPower Sound Source Type 4292-L
- Carrying Bag KE-0364 for Type 4292-L Tripod
- Lightweight Tripod UA-0801
- Speaker Cable AQ-0673, Speakon 4-pin (M) to Speakon 4-pin (M), 10 m (33 ft)
- Signal Cable AO-0523-D-100, Triaxial LEMO to XLR3M, 10 m (33 ft)
- 3 × Lightweight Tripod UA-0801
- Prepolarized Free-field 1/2" Microphone Type 4189
- Microphone Preamplifier ZC-0032 (for Type 2270)

Software and Accessories Available Separately

SOFTWARE MODULES

BZ-7228	Building Acoustics Software for Types 2250 and 2270
BZ-7228-100	Upgrade of BZ-7227 Reverberation Time software to BZ-7228 Building Acoustics Software
BZ-7229	Dual-channel Building Acoustics Software for Type 2270
BZ-7229-100	Upgrade of BZ-7228 to BZ-7229 Dual-channel Building Acoustics for Type 2270
BZ-7223	Frequency Analysis Software
BZ-7224	Logging Software
BZ-7225	Enhanced Logging Software
BZ-7225-UPG	Upgrade from Logging Software BZ-7224 to Enhanced Logging Software BZ-7225 (does not include memory card)
BZ-7226	Signal Recording Option (requires SD memory card or USB stick for analyzer)
BZ-7227	Reverberation Time Software
BZ-7230	FFT Analysis Software
BZ-7231	Tone Assessment Option

PC SOFTWARE

BZ-5503-A	Measurement Partner Suite, Logging Module
BZ-5503-B	Measurement Partner Suite, Spectrum Module
Type 8780	PULSE Reflex Building Acoustics
Type 8780-UPG	PULSE Reflex Building Acoustics – upgrade from Qualifier Type 7830
Type 7830	Qualifier

MEASUREMENT ACCESSORIES

AO-0440-D-015	Signal Cable, LEMO to BNC, 1.5 m (5 ft)
AO-0646	Sound Cable, LEMO to Minijack, 1.5 m (5 ft)
AO-0697-030	Microphone Extension Cable, 10-pin LEMO, 3 m (10 ft)
AO-0697-100	Microphone Extension Cable, 10-pin LEMO, 10 m (33 ft)

Service Products

ACCREDITED CALIBRATION

2250/2270-CAI	Accredited Initial Calibration of Types 2250/2270
2250/2270-CAF	Accredited Calibration of Types 2250/2270
2250/2270-CTF	Traceable Calibration of Types 2250/2270

TRADEMARKS

Microsoft, Windows, Excel and Windows Vista are registered trademarks of Microsoft Corporation in the United States and/or other countries · Pentium is a registered trademark and Core a trademark of Intel Corporation or its subsidiaries in the United States and/or other countries · JavaScript is a registered trademark of Sun Microsystems Inc. · Speakon is a registered trademark of Neutrik AG

Brüel & Kjær reserves the right to change specifications and accessories without notice. © Brüel & Kjær. All rights reserved.

- Dual 10-pole Adaptor JP-1041
- Flat Cable AR-0199, 10-pin LEMO, 0.5 m (1.64 ft)
- 2 × 1/2" Microphone Holder UA-1317
- 2 × Windscreen for 1/2" Microphones UA-0237, 90 mm diameter
- 2 × Microphone Extension Cable AO-0697-100, 10-pin LEMO, 10 m (33 ft)
- PULSE Reflex Building Acoustics Type 8780

BZ-7228-200

Building Acoustics Kit

As per Type 2250-J-001 or Type 2270-J-001, excluding Hand-held Analyzer. For Type 2250/2270 users intending to upgrade to a full Building Acoustics measurement system

BZ-7229-200

Dual-channel Building Acoustics Kit

As per Type 2270-K-001, excluding Type 2270. For Type 2270 users intending to upgrade to a full Dual-channel Building Acoustics measurement system

AR-0199

Flat Cable, 10-pin LEMO, 0.5 m (1.64 ft)

JP-1041

Dual 10-pole Adaptor

UA-0587

Tripod

UA-0801

Lightweight Tripod

UA-1317

1/2" Microphone Holder

UA-1404

Outdoor Microphone Kit

UL-1009

SD Memory Card for Hand-held Analyzers

UL-1017

SDHC Memory Card for Hand-held Analyzers

ZG-0444

Charger for Battery Pack QB-0061

Type 3923

Rotating Microphone Boom

Brüel & Kjær supplies a wide range of microphones and microphone accessories. Please contact your local Brüel & Kjær office for more information regarding the different types and their use, or visit the website at www.bksv.com.

INTERFACING

AO-1449-D-010 LAN Cable

UL-0250

USB to RS-232 Converter

SOUND SOURCES

Type 4292-L

OmniPower Sound Source

Type 4295

OmniSource Sound Source

Type 4224

Portable Battery & Mains Powered Sound Source

Type 3207

Tapping Machine

Type 2734-A

Power Amplifier

For further information on sound sources and accessories please refer to the 'Sound Sources for Building Acoustics' product data, [BP 1689](#).

CALIBRATORS AND PISTONPHONES

Type 4231

Sound Calibrator

Type 4226

Multifunction Acoustic Calibrator

Type 4228

Pistonphone

HARDWARE MAINTENANCE

2250/2270-EW1	Extended Warranty, one year extension (Types 2250/2270)
---------------	---

